



# Troubleshooting Guide

## Round Two Piece Toilet with Trip Lever

DEFECTS	PROBABLE CAUSES	CORRECTIVE ACTION
A) Slow filling of Tank with water	1 - Dirty water in water piping	1 - Clean piping at water inlet
	2 - Inlet Water Valve partly closed	2 - Open the valve
	3 - Screw that regulates water inlet is not adjusted properly	3 - Adjust the screw (no. 2 of Figure 2)
	4 - Low pressure in hydraulic installation	4 - Check water installation
B) Constant leaks in the Bowl	1 - Float set at a level too high above the overflow pipe (no. 8, Figure 3)	1 - Adjust the water level screw (no. 1 of Figure 2)
	2 - Bead Chain too tight	2 - Adjust the Bead Chain
	3 - Float stuck against the assembly or against the Tank's inside wall	3 - Free the Float
	4 - Seat of Flap Valve is damaged	4 - Replace Water Outlet Valve
	5 - Flap is deformed	5 - Replace Flap
	6 - Crack in the overflow pipe of Water Outlet Valve	6 - Replace Water Outlet Valve
C) Excessive noise on filling of Tank with water	1 - Screw that regulates fill time is disadjusted	1 - Adjust the screw for slower filling time (Screw no. 2 of Figure 2)
	2 - High water pressure in water line	2 - Check hydraulic installation
D) Need to keep holding down Flush Tripping Button so flushing will work satisfactorily	1 - Bead Chain that activates Float is too tight	1 - Loosen the Bead Chain
E) Insufficient water level inside Tank	1 - Float Rod not adjusted properly	1 - Adjust rod or replace Float
	2 - Water Inlet Valve plugged up	2 - Unplug valve
	3 - Lack of water pressure	3 - Check hydraulic installation